



INSTALLATION INSTRUCTIONS

PECCSLM Series Power Exhaust for York 20 -25 Ton Units

Before Starting Installation

Warning

Severe injury can result from incorrect servicing. Only qualified HVAC service personnel should install, troubleshoot, repair or service HVAC and related HVAC equipment.

Always disconnect power before servicing. Please note some installation configurations may have more than one disconnect.

Important

Always follow all local building electrical codes.

Voltage	ProVent P/N	External Static Pressure (Inch W.G.)				FLA	Hp
		0.1	0.25	0.375	0.50		
208/230V/3Ph	PECCSLM243025CS PECCSLM243025MS	10,400	9,500	9,100	8,600	11.2	4 Hp Total (Qty. 2, 2 Hp)
460V/3Ph	PECCSLM243046CS PECCSLM243046MS					5.6	

PARTS INCLUDED	QTY.
#10 x 1/2 Sheet Metal Screw	23
3/16" Dia x 25' Pressure Tubing (w/Modulating Option Only)	1
Pressure Connection Port (w/Modulating Option Only)	1
Leg Kit	1
Blank Off Panel	1
Adapter Panel	1


Horizontal Discharge

For horizontal discharge configuration, power exhaust needs to be mounted to horizontal duct leading to the unit. Allow clearance for economizer outside air hood.


Installation Instructions (Vertical Discharge, Steps 1 Thru 3)

1. Remove horizontal duct opening panel from unit. Locate passage way for wiring into unit. This will consist of four wires to economizer and economizer logic (constant volume) and line voltage (if wiring line voltage to unit control panel).
2. Install a factory included adapter panel, position adapter panel on the bottom of opening and secure to unit with sheet metal screws provided.
3. Position power exhaust on the bottom of the adapter panel opening. A factory included blank off is provided and positioned at the top of the power exhaust (if needed). (ILL. 2)
4. Install the power exhaust over the opening and secure to unit with sheet metal screws provided. Caulk all mating flanges water tight.
5. For constant volume units (2 stage), position one set of 24V wires (yellow- yellow) to the economizer logic auxiliary switch and set accordingly. (See wiring diagram). The other set, position field end switch to activate at 100% open damper position.


ILL. 1



ILL. 2



ILL. 3 - Constant Volume Power Exhaust Wiring



- 1 Power Supply. Provide disconnect means and circuit protection as required. See power exhaust name plate for electrical ratings. If local codes allow connecting to the HVAC unit power, make sure the disconnect and incoming wiring are sized to handle the load of both the HVAC unit and the power exhaust.

To determine MCA with power exhaust: $\text{New MCA} = \text{MCA of Unit Only} + \text{MCA of Power Exhaust}$

- 2 Transformer, contactor and fuses are to be in a NEMA type electrical enclosure.
- 3 Field supplied end switch on economizer damper.
- 4 For voltage, refer to label on exterior of power exhaust cabinet.
- 5 For fuses, refer to label on exterior of Power Exhaust cabinet.

Example: With a unit that has $\text{MCA}=22.5$ amps and $\text{MOCP}=30$ amps,

$$\text{New MCA} = 22.5 \text{ amps} + 3 \text{ amps (example for power exhaust)} = 25.5 \text{ amps}$$


If the New MCA is less than the MOCP for the HVAC unit, you can tie the power wire to the HVAC contactor terminal strip, if the local code allows. Make sure tap off terminal block is capable for handling more than one unit.

If the new MCA is greater than the MOCP or local code requires, you must run power wire for the power exhaust to an external disconnect. Make sure the disconnect is sized properly for the power from the power exhaust as well as the HVAC unit.


For Constant Volume Only:

- For second stage blower, reach in the cabinet and feed the 24V Yellow wire leads (ILL 5) through the economizer divider, then feed the wires through the economizer top frame.
- Align and install the end switch on the indicated location from (ILL 6). Ensure switch actuated when damper fully opens make sure the switch does not interfere with damper travel.
- Connect the two yellow wires to the terminals on the end-switch.


ILL. 4




ILL. 6



ILL. 5



ILL. 7 - Modulating Power Exhaust Option Wiring



⚠ Power Supply. Provide disconnect means and circuit protection as required. See power exhaust name plate for electrical ratings. If local codes allow connecting to the HVAC unit power, make sure the disconnect and incoming wiring are sized to handle the load of both the HVAC unit and the power exhaust.

To determine MCA with power exhaust: $\text{New MCA} = \text{MCA of Unit Only} + \text{MCA of Power Exhaust}$

⚠ Transformer, contactor and fuses are to be in a NEMA type electrical enclosure.

⚠ Factory mounted 3/16" low pressure tubing.

⚠ 25 feet of 3/16" high pressure tubing and connection port provided for field mounting in conditioned space. Architectural finishing field provided. (Follow local codes.)

⚠ For fuse size, refer to label on exterior of power exhaust cabinet.

⚠ For voltage, refer to label on exterior of power exhaust cabinet.

If the Power Exhaust is installed with the Simplicity Smart Equipment (SSE) board, please change the following fan type settings:

Details <enter>

Control <enter>

Power Ex <enter>

Ex FType <enter>

"select" Non- Modulating <enter>

To change the setpoints for "ON" and "OFF"

EconDmpPos- FanOn <60% default>

EconDmpPos- FanOff <20% default>

The two blower modulating power exhaust has one motor/blower that will turn on at field determined O/A. This is achieved by wiring to the economizer logic auxiliary switch and setting the potentiometer. The other motor/blower is connected to a motor controller (VFD) that varies the speed to maintain an acceptable conditioned space pressure. The power exhaust system includes a low pressure transducer that compares room pressure to atmospheric. This transducer sends a signal to the motor controller (VFD) which varies the motor frequency in order to provide pressure relief.

1. Install 3/16" pressure tubing as per wiring diagram making sure it is not located near any S/A or R/A diffuser or door.
2. The VFD is factory pre programmed to accept the 0 to 10 VDC signal through the pressure transducer.

Pressure vs. VFD Frequency

Transducer Output Signal (VDC)	Conditioned Space Pressure (Inch W.G.)	VFD Setting (Hz)
0	0	0
1	0.01	6
2	0.02	12
3	0.03	18
4	0.04	24
5	0.05	30
6	0.06	36
7	0.07	42
8	0.08	48
9	0.09	54
10	0.10	60
VFD is factory set at 0.05 inches w.g. To change setting, move arrows up/down to set desired frequency that determines pressure requirement.		