

INSTALLATION INSTRUCTIONS ECOHPRS Series Horizontal Economizer

for

York PRESTIGE for ZX 04-07; ZY 04-06

# **Before Starting Installation**

Only qualified HVAC service personnel should install, troubleshoot, repair or service HVAC and related HVAC equipment.

# 🛦 warning

Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es).


# General

The instruction provides all the necessary information to properly field install the Economizer and Economizer Hood on the above indicated equipment.

# Step 1:

Verify all unit parts in box.

- 1 ea. Economizer (A)
- 1 ea. Economizer Hood (B)
- 1 ea. Center Post (C)
- 1 ea. Filler Panel (D) (For ECOHPRST Only)
- 1 ea. Filter Access Panel (E)
- 1 ea. Hardware Bag (Not shown):
  - 12 ea. Self-tapping #10 16 x ½ Screws 14 ft. - ½ x ½ Gasket



#### Step 2:

If the unit is connected to a horizontal return duct, the horizontal return duct must be removed to complete the installation of the horizontal flow economizer.


If the unit has never been connected to a horizontal return duct, remove the horizontal duct cover. Retain the horizontal duct cover and screws for later use.

Remove the lower access panel and discard. Retain

# Important


If supplied with power exhaust option, power exhaust power (Molex) connection is located on economizer next to its power connection. Make sure to plug in power exhaust when connecting economizer power in Step 3 of instructions below.


screws for later use. Remove the filter access panel. See Figure 2.



## Step 3: (if required)


Remove RAT sensor and bracket as shown in **Figure 3**. Retain RAT sensor with bracket and screw to install in Economizer.





## Step 4:

If the unit was not originally connected to a horizontal return duct, install horizontal duct cover, removed in **Step 2**, over the return opening in the bottom of the unit (use the screws that originally held the panel in place). Ensure that the edge of the horizontal duct cover facing the coil is under the raised tabs on the side of the opening. The panel must be installed with the insulation facing up.



Install center post (C) at the location shown in **Figure 4**. The location is critical to the fit up of the remaining parts. Secure with 4 self-tapping 10-16 x  $\frac{1}{2}$  screws provided with the economizer.




Figure 5


## Step 5: (if required)

Disconnect the RAT sensor from the harness removed in **Step 3**. Secure the RAT sensor and bracket removed in **Step 3** to the Economizer in the location shown in **Figure 5**.

Route RAT harness thru the hole shown in **Figure 5** BEFORE completing the installation of the Economizer. Locate the harnesses in **Step 7** and prep/connect before completing the economizer installation.

# Step 6:

Slide the Economizer (A) over return opening and into horizontal duct opening as shown below. Secure Economizer at the top and bottom with self-tapping  $10-16 \times \frac{1}{2}$  screws provided with the economizer.as shown in **Figure 6**.



# Step 7:

The connection of the wiring harnesses to the economizer controller should be done before the filter access panel is installed. Locate the harness in the return compartment with brown wire 845 and red wire 846. Connect this harness into the "24V-IN" connections on the economizer controller. Locate the harness in the return compartment with the black wire 840, white wire 841 and red wire 842. Connect this harness to the "SA BUS" connections on the economizer controller. Refer to the unit wiring diagram.


#### Step 8:


Reconnect power to the unit - follow all safety instructions, rules and codes.

See unit Installation, Operation and Maintenance manual for instructions to verify the unit controller and the economizer controller are communicating properly. After communication between the unit controller and the economizer control board has been verified, proceed to **Step 9**.

# Step 9:

Secure Filter Access Panel (E) using 2 screws retained in **Step 2** and 2 self-tapping  $10-16 \times \frac{1}{2}$  screws provided with Economizer, as shown in **Figure 7**.





# Step 12:

Install/Reinstall the horizontal return duct. Ensure the duct is completely air and water tight.

# Step 10:

Install the Economizer Hood (B) onto the unit. The top flange of the hood will fit under the roof of the unit - ECOHPRSS only  $% \left( {{\rm A}} \right)$  .

# Note: If installing ECOHPRSS skip Step 11 and go to Step 12

# Step 11:

Install Filler Panel (D) under top of RTU and over top of Economizer Hood (B). Secure the right side of Filler Panel (D) with 1 self-tapping 10-16 x  $\frac{1}{2}$  screw provided with Economizer and secure the left side with 1 screw that was retained in **Step 2**. **See Figure 9**.





Figure 10

ILL. 1 Control Wiring Diagram



NOTES:

Ensure actuator mode setting is set to 2-10VDC. (Whether this is CW or CCW depends on the model, ensure this is opposite to the spring return, may require flipping of the actuator).

OCCUPIED SETTING CHANGE TO EXTERNAL (UCD OCC TERMINAL) UNLESS SCHEDULE HAS BEEN PROGRAMMED USING COM BOARD ACCESSORY AND LAPTOP.

Details <enter> Zone <enter> Indoor <enter> OccMode <enter>

Change from schedule to external by moving joystick to the right, select external <enter> Ensure the OCC terminal on the UCB has a 24VAC signal present.

SET MINIMUM POSITION

Details <enter> Control <enter> Econ <enter> Setup <enter> Econ-En <enter> Ensure setting is YES (change to YES if currently set to NO <enter>) Cancel out Scroll Down to Econ-MinPos <enter> Set to desired opening % <enter>

Escape back to Main Menu (Allow up to five (5) minutes for changes to take effect).

AUnit wiring shown is used as reference only. Check unit wiring for actual unit wiring.

# STATE OF CALIFORNIA AIR ECONOMIZER CONTROLS ACCEPTANCE



		ICH-05-A (Revised 06/14)		CALIFORNIA ENERGY COMMISSION		
		ATE OF ACCEPTANCE		NRCA-MCH-05-A		
	ECONO	mizer Controls Acceptance	Enforcement Agency	(Page 1 of 3)		
Projec	t Name:		Enforcement Agency:	Permit Number:		
Projec	t Address:	:	City:	Zip Code:		
Syster	n Name or	r Identification/Tag:	System Location or Area Served:			
Note	e: Sub	mit one Certificate of Acceptance for each syste	em that must Enforcement Agency U	se: Checked by/Date		
		ate compliance.				
A. C	onstru	iction Inspection				
1.	Supp	porting documentation needed to perform test i	ncludes:			
	a. 2013 Building Energy Efficiency Standards Nonresidential Compliance Manual (NA7.5.4 Air Economizer Controls Acceptance At - Glance).					
	b.	2013 Building Energy Efficiency Standards.				
2.	Instr	umentation to perform test includes:				
	a.	Hand-held temperature probe				
		Calibration Date:(mus	t be within last year)			
	b.	Device capable of calculating enthalpy				
	Calibration Date:(must be within last year)					
	с.	1.2 k Ohm Resistor ( when specified by the man	nufacturer)			
3.	Insta	allation: (all of the following boxes should be che	ecked)			
		Economizer high limit shutoff control com Section 140.4(e)3.				
	Economizer reliability features are present per 2013 Building Energy Efficiency Standards Section 140.4(e)4:					
		a. 5-year manufacturer warranty of o		0 actuations		
			eet proving capability of at least 60,00	indard 500 damper leakage at 10 cfm/sf at 1.0		
		in w.g. A product specification	sheet showing the manufacturer's res certification by a third party under AM	ults after following the testing procedures of CA Publication 511 can be used to satisfy this		
		d. If the high limit setpoint is fixed de setpoint	ry-bulb or fixed enthalpy + fixed dry-bu	Ib then the control shall have an adjustable		
		e. Outdoor air, return air, mixed air,	and supply air sensors shall be calibrat	ed as follows:		
		i. Drybulb and wetbulb tem	pperatures accurate to $\pm 2^{\circ}$ F over the ra	nge of 40°F to 80°F		
		ii. Enthalpy accurate to ±3	Btu/Ib over the range of 20 Btu/Ib to 3	6 Btu/lb		
		iii. Relative humidity (RH) a	ccurate to $\pm 5\%$ over the range of 20%	to 80% RH		
		f. Check that the sensor performanc calibration are plotted on the p		d sensor output values measured during sensor		
		g. Sensors used for high limit contro shielded from direct sunlight.	I shall be located to prevent false readi	ngs, including but not limited to being properly		
		Unitary systems with an economizer have compressors off when economizers can pr		r electronic thermostats, that cycle		
		System has return fan speed control, relie economizer mode.	f dampers, or dedicated relief fans to p	revent building over pressurization in full		
		For systems with DDC controls, sensor use	d for economizer lockout has been fac	tory or field calibrated.		
		For systems with non-DDC controls, manu	facturer's startup and testing procedu	res have been applied.		

# STATE OF CALIFORNIA AIR ECONOMIZER CONTROLS ACCEPTANCE CEC-NRCA-MCH-05-A (Revised 06/14)

CALIFORNIA ENERGY COMMISSION

CERTIFICATE OF ACCEPTANCE	NRCA-MCH-05-A			
Air Economizer Controls Acceptance		(Page 2 of 3)		
Project Name:	Enforcement Agency:	Permit Number:		
Project Address:	City:	Zip Code:		
System Name or Identification/Tag:	System Location or Area Served:			

В.	Functional Testing	Results
Step	o 1: Disable demand control ventilation systems (if applicable)	
Step	2: Enable the economizer and simulate a cooling demand large enough to drive the economizer fully open. Verify the f	ollowing:
a.	Economizer damper modulates 100% open.	Y / N
b.	Return air damper modulates 100% closed.	Y / N
c.	c. For systems that meet the criteria of 2013 Building Energy Efficiency Standards Section 140.4(e)1, verify that the economizer remains 100% open with the use of mechanical cooling. This occurs when the cooling demand can no longer be met by the economizer alone.	
d.	All applicable fans and dampers operate as intended to maintain building pressure.	Y / N
e.	The unit heating is disabled (if applicable).	Y / N / NA
Step	o 3: Disable the economizer and simulate a cooling demand. Verify the following:	
a.	B. Economizer damper closes to its minimum position.	
b.	All applicable fans and dampers operate as intended to maintain building pressure.	Y / N
c.	The unit heating is disabled (if applicable).	Y / N / NA
Step	9 4: If the unit is equipped with heating, simulate a heating demand and enable the economizer. Verify the following:	
a.	Economizer damper closes to its minimum position.	Y / N / NA
b.	Return air damper opens.	Y / N / NA
Step	o 5: Turn off the unit and verify the following:	
a.	Economizer damper closes completely.	Y / N
Ster	o 6: System returned to initial operating conditions	Y / N

C. Testing Results	PASS	/ FAIL
Step 2: Simulate cooling load and enable the economizer (all answers are Y).		
Step 3: Simulate cooling load and disable the economizer (all answers are Y).		
Step 4: Simulate heating demand and enable the economizer (all answers are Y).		
Step 5: Turn off the unit (all answers are Y).		

D. Evaluation :

PASS: All Construction Inspection responses are complete and all Testing Results responses are "Pass"

Natas		
Notes:		





	R ECONOMIZER CONTROLS ACC NRCA-MCH-05-A (Revised 06/14)			CALIFOR		
CEF	RTIFICATE OF ACCEPTANCE				NRCA-MCH-05-A	
	Economizer Controls Acceptance				(Page 3 of 3)	
Proje	ct Name:	Enford	cement Agency:		Permit Number:	
Proje	ct Address:	City:			Zip Code:	
Syste	m Name or Identification/Tag:	Syster	n Location or Area Served:			
DO	CUMENTATION AUTHOR'S DECLARATION STATEM					
	I certify that this Certificate of Acceptance docum		ate and complete			
	imentation Author Name:		Documentation Author Signature:			
Doci	imentation Author Company Name:		Date Signed:	Date Signed:		
Addı	ress:		ATT Certification Identification (	If applicable):		
City/	State/Zip:		Phone:			
FIF	LD TECHNICIAN'S DECLARATION STATEMENT					
	I certify the following under penalty of perjury, ur	nder the laws of t	he State of California:			
1.	The information provided on this Certificate of Ac					
2.	I am the person who performed the acceptance v	-		ceptance (Fi	eld Technician).	
3.	The construction or installation identified on this indicated in the plans and specifications approved requirements and procedures specified in Reference.	d by the enforcen	nent agency, and conforms t	••		
4.	I have confirmed that the Certificate(s) of Installar been completed and signed by the responsible bu issued for the building.	tion for the const	truction or installation ident		•	
Field	Technician Name:		Field Technician Signature:			
Field	Technician Company Name:		Position with Company (Title):			
Addı			ATT Certification Identification (if applicable):			
City/	State/Zip:		Phone:	D	ate Signed:	
RES	PONSIBLE PERSON'S DECLARATION STATEMENT					
1.	I certify the following under penalty of perjury, ur I am the Field Technician, or the Field Technician information provided on this Certificate of Accept	is acting on my b		y agent and	I have reviewed the	
2.	I am eligible under Division 3 of the Business and system design, construction or installation of feat identified on this Certificate of Acceptance and at	Professions Code ures, materials, c	components, or manufacture	ed devices f	or the scope of work	
3.	The information provided on this Certificate of Acceptance substantiates that the construction or installation identified on this Certificate of Acceptance complies with the acceptance requirements indicated in the plans and specifications approved by the enforcement agency, and conforms to the applicable acceptance requirements and procedures specified in Reference Nonresidential Appendix NA7.					
4.	I have confirmed that the Certificate(s) of Installation for the construction or installation identified on this Certificate of Acceptance has been completed and is posted or made available with the building permit(s) issued for the building.					
5.	I will ensure that a completed, signed copy of this permit(s) issued for the building, and made availa signed copy of this Certificate of Acceptance is recowner at occupancy.	ble to the enforc	ement agency for all application	able inspect	ions. I understand that a	
Res	ponsible Acceptance Person Name:		Responsible Acceptance Person	Signature:		
Res	ponsible Acceptance Person Company Name:		Position with Company (Title):			
Add	ress:		CSLB License:	CSLB License:		
City/State/Zip:		1				