

INSTALLATION INSTRUCTIONS ECOHPRL Series Horizontal Economizer for

York PRESTIGE for ZX 08-14; ZY 07-12

Before Starting Installation

Only qualified HVAC service personnel should install, troubleshoot, repair or service HVAC and related HVAC equipment.



General

The instruction provides all the necessary information to properly field install the Economizer and Economizer Hood on the above indicated equipment.

Step 1:

Verify all unit parts in box.

1 ea. - Economizer (A)

1 ea. - Economizer Hood (B)

1 ea. - Center Post (C)

1 ea. - Filler Panel (D) (For ECOHPRLT Only)

1 ea. - Filter Access Top Panel (E)

1 ea. - Horizontal Filler Panel (F) (For ECOHPRLT Only)

1 ea. - Hardware Bag (Not shown):

12 ea. - Self-tapping #10 - 16 x ½ Screws
14 ft. - ½ x ½ Gasket

(E)

Figure 1

Step 2:

Form: ECO-87-R1


If the unit is connected to a horizontal return duct, the horizontal return duct must be removed to complete the installation of the horizontal flow economizer.

Important

If supplied with power exhaust option, power exhaust power (Molex) connection is located on economizer next to its power connection. Make sure to plug in power exhaust when connecting economizer power in Step 3 of instructions below.


If the unit has never been connected to a horizontal return duct, remove the horizontal duct cover. Retain the horizontal duct cover and screws for later use.

Remove the lower access panel and discard. Retain screws for later use. Remove the filter access panel. See Figure 2.



Step 3: (if required)


Remove RAT sensor and bracket as shown in Figure 3. Retain RAT sensor with bracket and screw to install in



Note: If the unit was originally installed with a horizontal return duct, the return opening in the bottom of the unit will be covered.

Step 4:

If the unit was not originally connected to a horizontal return duct, install horizontal duct cover, removed in Step 2, over the return opening in the bottom of the unit (use the screws that originally held the panel in place). Ensure that the edge of the horizontal duct cover facing the coil is under the raised tabs on the side of the opening. The panel must be installed with the insulation facing up.



Install center post (C) at the location shown in **Figure 4**. The location is critical to the fit up of the remaining parts. Secure with 4 self-tapping $10-16 \times \frac{1}{2}$ screws provided with the economizer.




Figure 5


Step 5: (if required)

Disconnect the RAT sensor from the harness removed in **Step 3**. Secure the RAT sensor and bracket removed in **Step 3** to the Economizer in the location shown in **Figure 5**.

Route RAT harness thru the hole shown in **Figure 5** BEFORE completing the installation of the Economizer. Locate the harnesses in **Step 7** and prep/connect before completing the economizer installation.

Step 6:

Slide the Economizer (A) over return opening and into horizontal duct opening as shown below. Secure Economizer at the top and bottom with self-tapping 10-16 x $\frac{1}{2}$ screws provided with the economizer as shown in **Figure 6**.



Step 7:

The connection of the wiring harnesses to the economizer controller should be done before the filter access panel is installed. Locate the harness in the return compartment with brown wire 845 and red wire 846. Connect this harness into the "24V-IN" connections on the economizer controller. Locate the harness in the return compartment with the black wire 840, white wire 841 and red wire 842. Connect this harness to the "SA BUS" connections on the economizer controller. Refer to the unit wiring diagram.

Step 8:

Reconnect power to the unit - follow all safety instructions, rules and codes.

See unit Installation, Operation and Maintenance manual for instructions to verify the unit controller and the economizer controller are communicating properly. After communication between the unit controller and the economizer control board has been verified, proceed to **Step 9**.

Step 9:

Secure Filter Access Panel (E) using 2 screws retained in **Step 2** and 2 self-tapping 10-16 x ½ screws provided with Economizer, as shown in **Figure 7**.

2




Figure 7


Step 10:

Install the Economizer Hood (B) onto the unit. The top flange of the hood will fit under the roof of the unit - ECOHPRLS only.

Note: If installing ECOHPRLS skip Step 11 and go to Step 12.

Step 11:

Install Filler Panel (D) under top of RTU and over top of Economizer Hood (B). Secure the right side of Filler Panel (D) with 1 self-tapping 10-16 x $\frac{1}{2}$ screw provided with Economizer and secure the left side with 1 screw that was retained in **Step 2**. Install Horizontal Filler Panel (F) over return opening. **See Figure 9**.



Step 12:

Install/Reinstall the horizontal return duct. Ensure the duct is completely air and water tight.





Figure 10

3

ILL. 1
Control Wiring Diagram



NOTES:

⚠Unit wiring shown is used as reference only. Check unit wiring for actual unit wiring

Ensure actuator mode setting is set to 2-10VDC. (Whether this is CW or CCW depends on the model, ensure this is opposite to the spring return, may require flipping of the actuator).

OCCUPIED SETTING CHANGE TO EXTERNAL (UCD OCC TERMINAL) UNLESS SCHEDULE HAS BEEN PROGRAMMED USING COM BOARD ACCESSORY AND LAPTOP.

Details <enter>
Zone <enter>

Indoor <enter>

OccMode <enter>

Change from schedule to external by moving joystick to the right, select external <enter> Ensure the OCC terminal on the UCB has a 24VAC signal present.

SET MINIMUM POSITION

Details <enter>

Control <enter>

Econ <enter>

Setup <enter>

Econ-En <enter>

Ensure setting is YES (change to YES if currently set to NO <enter>)

Cancel out

Scroll Down to Econ-MinPos <enter>

Set to desired opening % <enter>

Escape back to Main Menu (Allow up to five (5) minutes for changes to take effect).

STATE OF CALIFORNIA

AIR ECONOMIZER CONTROLS ACCEPTANCE



CEC-NRCA-MCH-05-A (Revised 06/14)

CALIFORNIA ENERGY COMMISSION

CERTIFICATE OF ACCEPTANCE	NRCA-MCH-05-A	
Air Economizer Controls Acceptance		(Page 1 of 3)
Project Name:	Enforcement Agency:	Permit Number:
Project Address:	City:	Zip Code:
System Name or Identification/Tag:	System Location or Area Served:	

Note: Submit one Certificate of Acceptance for each system that must	Enforcement Agency Use: Checked by/Date
demonstrate compliance.	

A. Co	onstru	uction Inspection			
1.	Supporting documentation needed to perform test includes:				
	 a. 2013 Building Energy Efficiency Standards Nonresidential Compliance Manual (NA7.5.4 Air Economizer Controls Acceptance At Glance). 				
	b.	2013 Building Energy Efficiency Standards.			
2.	Insti	rumentation to perform test includes:			
	a.	Hand-held temperature probe			
		Calibration Date:(must be within last year)			
	h	Device canable of calculating enthalpy			

c. 1.2 k Ohm Resistor (when specified by the manufacturer)
Installation: (all of the following boxes should be checked)

Calibration Date: ____

Economizer high limit shutoff control complies with Table 140.4-B found in the 2013 Building Energy Efficiency Standards Section 140.4(e)3.

Economizer reliability features are present per 2013 Building Energy Efficiency Standards Section 140.4(e)4:

- a. 5-year manufacturer warranty of economizer assembly
- b. Provide a product specification sheet proving capability of at least 60,000 actuations

__(must be within last year)

- c. Provide a product specification sheet proving compliance with AMCA Standard 500 damper leakage at 10 cfm/sf at 1.0 in w.g. A product specification sheet showing the manufacturer's results after following the testing procedures of AMCA Standard 500 or AMCA certification by a third party under AMCA Publication 511 can be used to satisfy this requirement (Class 1A, 1, and 2 are acceptable).
- d. If the high limit setpoint is fixed dry-bulb or fixed enthalpy + fixed dry-bulb then the control shall have an adjustable setpoint
- e. Outdoor air, return air, mixed air, and supply air sensors shall be calibrated as follows:
 - i. Drybulb and wetbulb temperatures accurate to $\pm 2\,^{\circ}\text{F}$ over the range of $40\,^{\circ}\text{F}$ to $80\,^{\circ}\text{F}$
 - ii. Enthalpy accurate to ±3 Btu/lb over the range of 20 Btu/lb to 36 Btu/lb
 - iii. Relative humidity (RH) accurate to ±5% over the range of 20% to 80% RH
- f. Check that the sensor performance curve(s) is provided by the factory and sensor output values measured during sensor calibration are plotted on the performance curve(s)
- g. Sensors used for high limit control shall be located to prevent false readings, including but not limited to being properly shielded from direct sunlight.

Unitary systems with an economizer have control systems, including two-stage or electronic thermostats, that cycle compressors off when economizers can provide partial cooling

System has return fan speed control, relief dampers, or dedicated relief fans to prevent building over pressurization in full economizer mode.

For systems with DDC controls, sensor used for economizer lockout has been factory or field calibrated.

For systems with non-DDC controls, manufacturer's startup and testing procedures have been applied.

STATE OF CALIFORNIA

Project Address:

AIR ECONOMIZER CONTROLS ACCEPTANCE

-	scor.	8	١.
70	10.0	а	
	ea	9	
W	600		
-		•	

Zip Code:

EC-NRCA-MCH-05-A (Revised 06/14)	RNIA ENERGY COMMISSION	
CERTIFICATE OF ACCEPTANCE	NRCA-MCH-05-A	
Air Economizer Controls Acceptance	(Page 2 of 3)	
Project Name:	Enforcement Agency:	Permit Number:

City:

System	Traine of identification (rag.			
В.	Functional Testing	Res	ults	
Step	1: Disable demand control ventilation systems (if applicable)			
Step	Step 2: Enable the economizer and simulate a cooling demand large enough to drive the economizer fully open. Verify the following:			
a.	Economizer damper modulates 100% open.	Υ/	/ N	
b.	Return air damper modulates 100% closed.	Υ/	/ N	
c. For systems that meet the criteria of 2013 Building Energy Efficiency Standards Section 140.4(e)1, verify that the economizer remains 100% open with the use of mechanical cooling. This occurs when the cooling demand can no longer be met by the economizer alone.			Y/N	
d.	All applicable fans and dampers operate as intended to maintain building pressure.	Y/N		
e.	The unit heating is disabled (if applicable).	Y/N/NA		
Step	3: Disable the economizer and simulate a cooling demand. Verify the following:			
a.	Economizer damper closes to its minimum position.	Υ/	Y/N	
b.	All applicable fans and dampers operate as intended to maintain building pressure.	Υ/	/ N	
c.	The unit heating is disabled (if applicable).	Y/N	Y/N/NA	
Step	4: If the unit is equipped with heating, simulate a heating demand and enable the economizer. Verify the following:			
a. Economizer damper closes to its minimum position.			Y/N/NA	
b. Return air damper opens.			Y/N/NA	
Step	5: Turn off the unit and verify the following:			
a.	Economizer damper closes completely.	Υ/	[/] N	
Step	6: System returned to initial operating conditions	Υ /	′ N	
C.	Testing Results	PASS	/ FAIL	
	2: Simulate cooling load and enable the economizer (all answers are Y).	 		
	3: Simulate cooling load and disable the economizer (all answers are Y). 4: Simulate heating demand and enable the economizer (all answers are Y).			
	5: Turn off the unit (all answers are Y).	 	-	
эсер	3. Talli on the anic fail answers are 1).	<u> </u>		
D.	Evaluation:			
	PASS: All Construction Inspection responses are complete and all Testing Results responses are "Pass"			
Note				

STATE OF CALIFORNIA

AIR ECONOMIZER CONTROLS ACCEPTANCE



CEC-I	NRCA-MCH-05-A (Revised 06/14)			CALIFOR	RNIA ENERGY COMMISSION
CEF	RTIFICATE OF ACCEPTANCE				NRCA-MCH-05-A
Air Economizer Controls Acceptance					(Page 3 of 3)
Projec	ct Name:	Enforce	ment Agency:		Permit Number:
Projec	ct Address:	City:			Zip Code:
Syster	m Name or Identification/Tag:	System	Location or Area Served:		
DO	CUMENTATION AUTHOR'S DECLARATION STATEMENT				
	I certify that this Certificate of Acceptance documentation is	accurat			
Docu	mentation Author Name:		Documentation Author Si	ignature:	
Docu	mentation Author Company Name:		Date Signed:		
Addr	ess:	ATT Certification Identification (If applicable):			
City/	State/Zip:		Phone:		
FIEI	LD TECHNICIAN'S DECLARATION STATEMENT				
	I certify the following under penalty of perjury, under the law	ws of th	e State of California:		
1.	The information provided on this Certificate of Acceptance is	s true a	nd correct.		
2.	I am the person who performed the acceptance verification	reporte	ed on this Certificate o	of Acceptance (F	ield Technician).
3.	3. The construction or installation identified on this Certificate of Acceptance complies with the applicable acceptance requirements indicated in the plans and specifications approved by the enforcement agency, and conforms to the applicable acceptance requirements and procedures specified in Reference Nonresidential Appendix NA7.				
4.	I have confirmed that the Certificate(s) of Installation for the been completed and signed by the responsible builder/instal issued for the building.	e constr	uction or installation		•
Field	Technician Name:		Field Technician Signature	e:	
Field	Technician Company Name:		Position with Company (T	Title):	
Addr	Address: ATT Certification (if applicable):				
City/	State/Zip:		Phone:	0	Date Signed:
RES	SPONSIBLE PERSON'S DECLARATION STATEMENT			L	
	I certify the following under penalty of perjury, under the law	ws of th	e State of California:		
1.	 I am the Field Technician, or the Field Technician is acting on my behalf as my employee or my agent and I have reviewed the information provided on this Certificate of Acceptance. 				
2.					
3.					
4.					
5.	5. I will ensure that a completed, signed copy of this Certificate of Acceptance shall be posted, or made available with the building permit(s) issued for the building, and made available to the enforcement agency for all applicable inspections. I understand that a signed copy of this Certificate of Acceptance is required to be included with the documentation the builder provides to the building owner at occupancy.				
Resp	oonsible Acceptance Person Name:		Responsible Acceptance	Person Signature:	
Resp	oonsible Acceptance Person Company Name:		Position with Company (Title):	
Addı	ress:		CSLB License:		
City/	/State/Zip:		Phone:	1	Date Signed: